


## Use Motion Launch™

When the screen is off and your phone is in sleep mode, you can quickly wake up the phone by using Motion Launch.

| To...                          | Pick up your phone in... | Then...      |
|--------------------------------|--------------------------|--------------|
| Wake up the screen             | portrait orientation     | Double tap   |
| Go to HTC BlinkFeed            |                          | Swipe right  |
| Go to the Home widget panel    |                          | Swipe left   |
| Return to your most recent app | landscape orientation    | Swipe up     |
| Launch Camera                  |                          | Press Volume |

To learn more, go to **Settings > Display & gestures > Motion Launch gestures**. Under **Help**, tap the items to see the tutorials.



## Keep in contact

### Check your contact list

Easily communicate with people that matter to you. The Contacts app lists all contacts you've stored on your phone and from online accounts you're logged in to.


1 Open the **Contacts** app.

2 On your contacts list, you can:

- View and edit your profile.
- Create, edit, find, or send contacts.

- Tap a contact photo to find ways to quickly connect with the contact.

- See a notification icon when a contact has sent you new messages.



### Add a new contact

1 On the Contacts tab, tap **+**.

2 Tap the **Name** field, and then enter the contact name.

3 Select the Contact type, which indicates the account the contact will sync with.

4 Enter the contact information in the fields provided.

5 Tap **Save**.

## Capture great moments

HTC One gives you a variety of capture modes to use — from the basic ones for taking regular photos and videos to advanced modes such as Pan 360.



### Zoe™ Camera mode

Zoe Camera mode lets you take photos, videos, and burst shots. Take different types of shots depending on how long you press the onscreen shutter.

- Tap **📷** to take a photo.
- Press and hold **📷** for up to three seconds to capture a short video clip along with burst shots.
- Press and hold **📷** over three seconds until you see the word **"Locked"** appear above the shutter to also record a longer video.

## Get creative with Duo Effects

Pictures taken with HTC One's Duo Camera are more than just ordinary photos. The depth sensor in HTC One makes it possible to apply many interesting special effects.

Snow at the beach, silly stickers and more. With HTC's Gallery app, you can have fun with your Duo Camera photos before you share them on your social networks.

To apply Duo Effects to a photo, in Gallery open the photo you want in full screen, tap it, and then tap **Edit**.

Tap **Effects** to choose from six different Duo Effects:

|                 |                                                                          |
|-----------------|--------------------------------------------------------------------------|
| UFocus™         | Change the focus of a subject or object by just tapping it on the photo. |
| Seasons         | Choose from four different themes.                                       |
| Foregrounder    | Change the background of a photo.                                        |
| Dimension Plus™ | View objects from different angles in a photo.                           |

## Sync music and more

Whether you're at your computer or on the move, HTC Sync Manager lets you enjoy the same rich media. It also stores your same contacts, documents, and other data on both your phone and your computer (compatible with Windows® and Mac OS®).

And, you can use HTC Sync Manager to easily transfer iPhone photos, text messages, contacts, and more to your phone.

### Install HTC Sync Manager

- 1 Download the HTC Sync Manager installer from the HTC support site ([www.htc.com/hsm/](http://www.htc.com/hsm/)).
- 2 Launch the installer and follow the onscreen instructions.
- 3 Connect your phone to your computer using the supplied USB cable. HTC Sync Manager opens.

## Keep it kid-friendly

Worried that your kids might wander off to inappropriate web sites or mess with your important work files while using your phone? With Kid Mode®, your children have their own space to enjoy:

- Parent-approved games and apps
- Recorded storybook readings
- Age-appropriate features such as an art board, video messaging, and more

Open the Kid Mode app and follow the instructions to set up your account. To learn more about Kid Mode, visit [www.zoodles.com](http://www.zoodles.com).

## Download more apps

Find new apps in Google Play™ Store for your phone. Choose from a wide variety of free and paid apps ranging from productivity apps, entertainment, to games.

- 1 Open the **Play Store** app.
- 2 Browse or search for an app.
- 3 When you find the app that you like, tap it and read its description and user reviews.
- 4 To download or purchase the app, tap **Install** (for free apps) or the price button (for paid apps).
- 5 Tap **Accept**.

## Accessories

Whether you want a charger, a fashionable carrying case, a Bluetooth headset, or you just want to browse for fun extras, T-Mobile is the place to shop for all your phone accessories.

Here are a few examples...



Portable Battery Pack



Headset



MicroUSB Car Charger

To purchase accessories for your phone, visit [T-Mobile.com](http://T-Mobile.com), call 1.800.204.2449, or visit your nearest T-Mobile store.

Accessory selection subject to change and may vary by location.

### ADDITIONAL INFORMATION

Use of some features, content or services may incur separate, additional charges and/or require a qualifying service, or access to a Wi-Fi connection.

**Messaging/Data:** You will be charged for all messages and data sent by or to you through the network, regardless of whether or not data is received. Character length/file size of messages/attachments may be limited. T-Mobile is not liable for content of messages/attachments or for any failures, delays or errors in any T-Mobile generated alerts or notifications. Your data session, plan, or service may be **slowed, suspended, terminated, or restricted** if you use your service in a way that interferes with or impacts our network or ability to provide quality service to other users, if you roam for a significant portion of your usage, or if you use a disproportionate amount of bandwidth during a billing cycle. You may not use your plan or device for prohibited uses.

**Downloads/Applications:** T-Mobile is not responsible for any third party content or Web site you may be able to access using your phone. Additional charges may apply; not all downloads available on all phones. You obtain no rights in downloads; duration of use may be limited and downloads may be stored solely for use with your phone. T-Mobile is not responsible for any download lost due to your error. T-Mobile is not responsible for Apps, including download, installation, use, transmission failure, interruption or delay, third party advertisements you may encounter while using an App, alterations any App may make to the functionality of your device, **including any changes that may affect your T-Mobile plan, service, or billing, or any content or website you may be able to access through an App.**

**Mobile Security:** Capable phone required; technical limitations may prevent certain features (e.g., LOCK) from working on certain phones. Enabling the location history features of Mobile Security can cause your phone's battery life to diminish more quickly. Device must be powered on, have text messaging capability, and be within the T-Mobile coverage area for Mobile Security features to function. Data usage applies for download and use of Mobile Security. As with other software, Mobile Security may be disabled or uninstalled by other applications, software, devices or hacking. In this event the protective features of Mobile Security may not function properly. In addition, even though installed, Mobile Security may not function properly due to other prior installed software on your device.

**Coverage:** Not available in some areas.

Devices, screen, and accessory images are simulated. See brochures and **Terms and Conditions (including arbitration provision)** at [T-Mobile.com](http://T-Mobile.com), for rate plan information, charges for features and services, coverage maps, and restrictions and details.


T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. © 2014 T-Mobile USA, Inc. HTC, the HTC logo, HTC One, and Zoe are trademarks of HTC Corporation. Google and Google Play are trademarks of Google Inc. Kid Mode is a trademark of Inquisitive Minds, Inc. Mac OS is a trademark of Apple Inc. Windows is a trademark of Microsoft Corporation.

| CEC Appliance Efficiency Compliance                                                 |                                                                                                                                                                                                                                                            |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | The BC logo (shown at the left) indicates that this product complies with the California Energy Commission (CEC) energy efficiency standards for battery charger systems set forth at California Code of Regulations Title 20, Sections 1601 through 1608. |



# Welcome

## Start Guide



htc one® (M8)



# Before you do anything else, please read this

## Safety tips

### Consider device compatibility

If you have a pacemaker or hearing aid, check with your doctor to make sure it is safe for you to use a cell phone. In some cases, cellular radio frequencies can disrupt the performance of other electronic equipment. If you have questions about the interaction between your phone and any other piece of electronic equipment, ask the equipment manufacturer.

## Drive safely

When you are driving, T-Mobile encourages you to use your phone in a safe and sensible manner. Here are a few tips:

- Assess road conditions before answering your phone. Your safety is more important than any call.
- Prepare your hands-free headset, if you have one, or turn on your speakerphone, before you start moving.
- Keep your phone close. If it rings and you discover it's in the back seat, do NOT crawl over the seat to answer it while driving.
- Remember that laws prohibiting or restricting the use of a cell phone while driving may apply in your area.

## Emergency dialing

Although all phones are equipped with 9-1-1 emergency calling, this phone may or may not permit its location to be approximated during a 9-1-1 call.\*

\* Availability of this feature depends on upgrades to the (a) wireless network and (b) 9-1-1 calling system that are required to be installed by the local 9-1-1 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength, and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped, or refused. The phone's approximate location is transmitted to the local 9-1-1 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions and Privacy Policy for additional service restrictions and details.

## Information about safeguarding handsets

T-Mobile encourages customers to take appropriate measures to secure their handsets and invites them to take advantages of the features available on this handset to help secure it from theft and/or other unauthorized access and use. This handset has a locking function (e.g., user-defined codes or patterns) that can serve as a first line of defense against unauthorized use or access to stored information. Preloaded security applications that allow customers to track or locate misplaced devices can be found on several T-Mobile devices. Lost or stolen devices should be immediately reported to T-Mobile so that proper measures can be taken to protect accounts. For additional information visit: [www.t-mobile.com/devicesecurity](http://www.t-mobile.com/devicesecurity) and <http://www.t-mobile.com/Company/PrivacyResources.aspx>.

**Approved Firmware Versions:** This device will only operate with firmware versions that have been approved for use by T-Mobile and the device manufacturer. If unauthorized firmware is placed on the device it will not function.

## Get to know your phone



## Set up your phone

### Insert the nano SIM and microSD cards

#### IMPORTANT:

**Use the nano SIM provided in the box only.**


Inserting a modified card may cause the card to not fit properly or damage the card slot.

- 1 Insert the tip of the tray eject tool (or a small bent paperclip) into the hole next to the nano SIM card tray that's on the left side of the phone. Push the tip all the way into the hole until the tray ejects, and then pull the tray out.

- 2 Place the nano SIM card (contacts facing down) into the tray, and then insert the tray back into the slot.


- 3 Use the same tray eject tool to eject the microSD card tray that's on the right side of the phone. Pull the tray out.

- 4 Place the microSD card (contacts facing down) into the tray, and then insert the tray back into the slot.



### Charge the phone

- 1 Connect the phone to the power adapter using the provided USB cable.
- 2 Plug the power adapter into an electrical outlet to start charging.



### Turn on the phone

- 1 To turn on the phone, press and hold the POWER button.
- 2 When the phone goes to sleep mode, briefly press the POWER button and then drag the lock icon up to unlock.


### Sign in to your phone

When you switch on your new phone for the first time, you'll be asked to set it up.

Walk through the on-device setup to choose your Internet connection, select how you want to set up your new phone, and more.

## Be in the know

HTC BlinkFeed™ discovers stories and articles automatically based on your interests, favorite categories, and popular news channels or websites. You can also see what's happening with friends in your social networks, TV program reminders, upcoming calendar events, and more.




Choose what you want to appear on HTC BlinkFeed. You can choose from sources such as content categories, social networks, services, and apps. Just swipe right to open the slideout menu, and then tap  to choose what you want.

## Define your style

Make your phone look and sound just the way you want it. Set a different wallpaper, and change your ringtone and notification sounds.

### Change your home wallpaper

- 1 Press and hold an empty space on a home widget panel.
- 2 In the pop-up menu, tap **Home screen wallpaper**.
- 3 Choose from where you want to select the wallpaper, such as Gallery.
- 4 Tap **Done**.



You can also change the lock screen wallpaper.

Go to **Settings > Personalize > Lock screen wallpaper**, and then choose whether to use the home screen wallpaper or a custom wallpaper from Gallery.

### Pick ringtones and sounds

- 1 With two fingers, swipe down from the status bar to open Quick Settings, and then tap  > **Personalize**.
- 2 Under **Sound**, change the ringtone, notification sound, and alarm.

Go to the Messages, Mail, and Calendar apps to choose sounds for new messages, email, and calendar reminders respectively.

### Add a widget panel

Get more space to create shortcuts to apps, frequently used settings, bookmarked webpages, and more.

- 1 Press and hold an empty space on a widget panel.
- 2 In the pop-up menu, tap **Manage home screen pages**.
- 3 To add a new widget panel, swipe left until you see the  icon, and then tap it.

### Choose launch bar shortcuts

Fill the launch bar with apps you often use for one-touch access.

- To remove an app, press and hold the app and drag it out of the launch bar and into a Home widget panel.



- To add an app, press and hold an app and then drag it to an empty slot on the launch bar.
- To group apps on the launch bar into a folder, just press and hold an app, and then drag it over to another app.



TC521183.1

